

# Bowtech BT-X 31" Cam X30 Mod

## Stop Compatibility Chart

Shorter Draw	Compatible Stops		A4 B4 C4 D4	A4 B4 C4	A4 B4 C4	A4 B4 C4	A4 B4 C4	A4 B4 C4	A4 B4 C4
	Stop Position #		Stop Position 2	Stop Position 3	Stop Position 4	Stop Position 5	Stop Position 6	Stop Position 7	
	MOD # X30 Draw Length	MOD 1	MOD 2	MOD 3	MOD 4	MOD 5	MOD 6	MOD 7	
		---	30"	29.5"	29"	28.5"	28"	27.5"	
Longer Draw	Stop Position #		Stop Position 1	Stop Position 2	Stop Position 3	Stop Position 4	Stop Position 5	Stop Position 6	
	Compatible Stops		A4 B4 C4 D4	A4 B4 C4 D4	A4 B4 C4	A4 B4 C4	A4 B4 C4	A4 B4 C4	A4 B4 C4

Shorter Draw	Compatible Stops	A4 B4 C4
	Stop Position #	Stop Position 8
	MOD # X30 Draw Length	MOD 8
		27"
Longer Draw	Stop Position #	Stop Position 7
	Compatible Stops	A4 B4 C4

Use this chart for stop compatibility for bow

Note:

- To increase draw length, let-off, valley length, stop will be put in 1 numerical position less than the module setting
- To decrease draw length, let-off, valley length, stop will be put in same position as module
- This chart is a place to start, different combinations may be used to achieve different effects of stops
- Please report an error or omission to Luck-Stops.com